



## **BLACK FOAM ROAD BIKE PODS SPECIAL INSTRUCTIONS**

### **WARNING**

Unifilter road bike pods must be oiled prior to use. However, do not use conventional "foam filter oils" or treatments. Use only 50:50 engine oil and petrol mix as the filter oiling fluid.

Unifilter road bike pods employ a small porosity foam and, combined with this 50:50 oil/petrol mix, will achieve very high air flow and dust retention qualities. Use of conventional filter oils will restrict the air flow of these pods.

### **Oiling**

Mix 50:50 engine oil and petrol. Saturate the pod filter foam with the mix and allow to stand until the petrol evaporates. Wipe off any excess mix from the pod foam, thoroughly clean pod snout and then fit.

### **Cleaning**

Wash out pod filter with petrol or mineral turps then re-oil as above.

### **UNIFILTER AUSTRALIA**

1/35 Leighton Place, Hornsby NSW 2077, Australia

☎ (02) 9482 1792 📠 (02) 9482 1790

[info@uniflow.com.au](mailto:info@uniflow.com.au)

[www.unifilter.com.au](http://www.unifilter.com.au)