

	XS1	EARLY	MID	LATE
		XS1B, XS2, TX	TX-A,XS-B, C, D, E, F	SE..., G...
Pressure Plate	256-16351-00-00	√	341-16351-01	√
Screw	90149-06102-00	√	90149-06077	90149-06102
Spring	90501-26148-00 90501-23142-00	√	√	90501-23142
Push Rod	256-16356-00	√	√	√
Nut	156-16174-00	√	√	√
Lock Washer	---	---	---	90215-19139
Spring Bellville	92901-18100-00	√	168-16185-00	---
Washer	92900-18200-00	√	92901-18200	90208-18025
Friction Plate	341-16321-03-00 (4) 256-16331-00-00 (2)	(3.5mm)√ (3.5mm)√	341- 1632113(3.0mm) ---	√(3.0mm) ---
Cushion Ring	---	256-16357-00- 00	---	---
Clutch Plate	256-16325-00-00	√	341-16325-01	√
Fitting ring	---	---	---	1T3-16385-00
Clutch Plate	---	---	---	256-16325-00
Cushion Spring	---	---	---	2H7-16383-00
Set Plate	---	---	---	2H7-16384-00
Clutch Boss	256-16371-09-00	√	341-16371-01	1T3-16370-00
Thrust Plate(25-50-2)	---	170-16164-00	√	√
Needle Bearing	93341-23504-00	√	√	√
Thrust Plate (35-51-0.5)	??	??	√	√
Primary Drive Hub	??	??	??	??
Primary Drive Gear 72T	256-16150-02	√	√	√
Spacer	256-16181-01	√	√	√
Thrust Washer (25-50-2)	170-16164-00	√	√	√
Washer (25.2-36-1.0)	131-15653-00	√	√	√
Ball (5/16")	93505-16006	√	√	√
Push Rod	256-16357-00	√	447-16357-00	341-16376-00
Ball (5/16")	---	---	93505-16006	√
Push Rod	---	---	341-16376-00	447-16357-00
Seal (8-25-6)	93102-08118	√	√	√
Worm Drive Assy	256-16340-09-00	447-16340-00	√	1T3-16340-00
...the rest of the worm is	the same for all the	models		