



## OIL PUMP

Ref. No.	Part Number	Description	Qty	Remarks
1	256-00001-01-00	. COVER, PUMP .....	1	N/A
	256-13316-02-00	. COVER, PUMP .....	1	
2	(256-13310-01-00)	ROTOR ASSEMBLY 1 .....	1	
	256-13310-02-00	. ROTOR ASSEMBLY 1 .....	1	130-XS1-022832XS1B022833-
3	(256-13314-01-00)	. SHAFT, PUMP .....	1	
4	93603-17070-00	PIN, DOWEL .....	1	
5	90280-03023-00	KEY, WOODRUFF .....	1	
6	256-13325-00-00	GEAR, PUMP DRIVEN .....	1	
7	95380-06600-00	NUT .....	1	
8	92995-06100-00	WASHER, SPRING .....	1	
9	93501-04011-00	BALL .....	1	
10	(256-13484-00-00)	SPRING, RELIEF .....	1	PN320
11	90430-08020-00	GASKET .....	1	PN320
12	92501-08010-00	SCREW, PAN HEAD .....	1	PN320
13	98580-06020-00	SCREW .....	3	
14	93604-12037-00	. PIN, DOWEL .....	2	
15	256-13414-00-00	GASKET, STRNR COVER ....	1	
16	256-13411-01-00	STRAINER, OIL .....	1	
17	256-13417-00-00	COVER, STRAINER .....	1	
18	(95201-06040-00)	BOLT, FLAT HD.DRILL .....	3	
	97313-06040-00	BOLT, HEXAGON .....	3	
19	92995-06100-00	WASHER, SPRING .....	3	
20	97011-06025-00	BOLT (97001-06025) .....	6	
21	256-13441-00-00	ELEMENT, OIL CLNR .....	1	
22	256-13445-00-00	GASKET, ELEMENT .....	1	
23	256-13495-00-00	SCREW .....	1	
24	90501-07031-00	SPRING, COMPRESSION ....	1	
25	93501-04011-00	BALL .....	1	
26	90149-10019-00	SCREW, SPEC"L SHAPE ....	1	

CONTINUED ON NEXT FRAME ►

B6