

KICK STARTER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
15- 1	256-15660-02	KICK AXLE ASS'Y	1		
15- 2	256-15654-00	HOLDER	2		
15- 3	256-15673-00	CLIP	1		
15- 4	306-15641-00	GEAR, kick (25T)	1		
15- 5	256-15687-00	CLIP, kick	1		
15- 6	611-45567-00-05	SHIM (25.5-35-0.5)	1		
15- 7	256-15666-00	SPACER (25.4-53-4)	2		
15- 8	256-15665-00	SPRING, kick	1		
15- 9	256-15664-01	GUIDE, spring	1		
15-10	131-15653-00	SHIM (25.2-36-1.0)	2		
15-11	93410-25017	CIRCLIP	1		
15-12	93102-25064	OIL SEAL (SD-25-35-7)	1		
15-13	341-15621-00	BOSS, kick crank	1		
15-14	97101-08030	BOLT	1		
15-15	447-15611-00-93	CRANK, kick	1		
15-16	93505-16006	BALL (1/16 inch)	1		
15-17	168-15622-01	SPRING, boss stoper	1		
15-18	256-15615-00	WASHER	1		
15-19	93430-12022	CIRCLIP	1		
15-20	¹⁴ 256 -15618-00	COVER, kick lever	1		